



MELTBLOWN 90

Hygienic mask

REFERENCE: 50505

Disposable hygienic protection mask, reusable up to 5 washes at 60°, with three layers made of heat-sealed non-woven. It has elastic bands and an adaptable internal clip on the nose for a perfect fit.

Complies with European regulations, UNE 0065
Not suitable for medical use.

Minimum filtration efficiency 95%



Washing instructions

The mask supports 5 wash cycles at 60 ° C with detergent (normal washing machine cycle).

Contact between a dirty mask (to be washed) and clean clothing should be avoided. The person in charge of the washing must protect himself to handle the dirty masks.

Products that can degrade or damage the materials and that diminish their protective capacity must not be used.

It is recommended that the mask dry completely within 2 hours after washing. Do not tumble dry.

It should not be dried or sanitized with a microwave oven.

Never modify or repair the mask.



UNE
0065

Material

Non Woven

Minimum filtration efficiency

BFE ≥ 95%

MELTBLOWN 90%

N° of layers

3 layers (Meltblown 90%)

Usage

Disposable

Reusable up to 5 washes

Not suitable for medical use

Certificates:

UNE 0065

Test report

Intertek Certificated

Packing

50 pcs Individual box

2000pcs Carton box